

TECHNICAL DATA

All the facts at a glance



TYPE

Vibrations Sensor | Article-Nr.: 6107

TECHNICAL DETAILS

- Safeguarding valueable objects in indoor and outdoor areas like painting, vases, garden furniture or barbecues
- Detects touching and moving of objects
- Detection sensitivity adjustable in 2 steps
- Fixation by velcro strap or glue pad (included)
- Battery operated (1 x CR2430 button cell, included)
- Low battery warning at the base unit

DIMENSIONS

Height 40,1 mm x Width 40,1 mm x Depth 16,7 mm

WEIGHT

21 Gramm

FASTENING

Attachment with hook-and-loop fastener or adhesive pad. Included in the package.

